



# Concrete Curb, Type "III" Mod. & Brick Paver, Type "I", Inlay

**PAVER NOTES:**

1. PAVERS TYPE - SEE SITE LAYOUT FOR PAVER INFORMATION.
2. PROVIDE SURFACE APPLIED SEALER AFTER INSTALLATION.
3. INSTALL A GEOTEXTILE FILTER FABRIC OVER ENTIRE AREA TO BE PAVED TO COVER WEEP HOLES.
4. SET BRICK PAVERS IN RUNNING BOND PATTERN HAND TIGHT ON  $\frac{3}{4}$ " SETTING BED OF WASHED SAND MEETING ASTM C33 AND SWEEP JOINTS WITH GATOR MAXX POLYMERIC SAND, SLATE GREY COLOR, OR APPROVED EQUAL, PER MANUFACTURER'S INSTRUCTIONS.

**NOTE:**

EXPANSION JOINTS FOR CONCRETE BASE SHALL BE LOCATED EVERY 50 LF.

