



PAVER NOTES:

1. PAVERS TYPE "II" - SEE SITE LAYOUT FOR PAVER INFORMATION.
2. PROVIDE SURFACE APPLIED SEALER AFTER INSTALLATION.
3. INSTALL A GEOTEXTILE FILTER FABRIC OVER ENTIRE AREA TO BE PAVED TO COVER WEEP HOLES.
4. SET PAVERS HAND TIGHT ON  $\frac{3}{4}$ " SETTING BED OF WASHED SAND MEETING ASTM C33 AND SWEEP JOINTS WITH GATOR MAXX POLYMERIC SAND, SLATE GREY COLOR, OR APPROVED EQUAL, PER MANUFACTURER'S INSTRUCTIONS.

NOTE:

EXPANSION JOINTS FOR CONCRETE BASE SHALL BE LOCATED EVERY 50 LF.

